

| | | |
|--------------------|---------|---------------|
| Bluetooth Device | BlueAnt | Supertooth II |
| Bluetooth Device | Nokia | HS-55W |
| Bluetooth Device | Nokia | HS-54W |
| Bluetooth Device | Nokia | HS-53W |
| Bluetooth Device | Nokia | HS-4W |
| Bluetooth Device | Nokia | HS-3W |
| Bluetooth Device | Nokia | HS-21W |
| Bluetooth Device | Nokia | HS-13W |
| Bluetooth Device | Nokia | HS-12W |
| Bluetooth Device | Nokia | HS-11W |
| Bluetooth Device | Nokia | HDW-3 |
| Bluetooth Device | Nokia | EarSet 2 |
| Bluetooth Device | Nokia | BH-205 |
| Bluetooth Device | Nokia | BH-204 |
| Bluetooth Device | Nokia | BH-203 |
| Bluetooth Device | Nokia | HS-56W |
| GPS | Nokia | LD-1W |
| Mobile Phone / PDA | Nokia | 8800 |
| Mobile Phone / PDA | Nokia | 2115i |
| Mobile Phone / PDA | Nokia | 1110i |
| Mobile Phone / PDA | Nokia | 9500 |
| Mobile Phone / PDA | Nokia | 9300 |
| Mobile Phone / PDA | Nokia | 9290 |
| Mobile Phone / PDA | Nokia | 9200 |
| Mobile Phone / PDA | Nokia | 9110 |
| Mobile Phone / PDA | Nokia | 8910 |
| Mobile Phone / PDA | Nokia | 8890 |
| Mobile Phone / PDA | Nokia | 8860 |
| Mobile Phone / PDA | Nokia | 8855 |
| Mobile Phone / PDA | Nokia | 8850 |
| Mobile Phone / PDA | Nokia | 8810 |
| Mobile Phone / PDA | Nokia | 8801 |
| Mobile Phone / PDA | Nokia | 2116i |
| Mobile Phone / PDA | Nokia | 2125i |
| Mobile Phone / PDA | Nokia | 5160i |
| Mobile Phone / PDA | Nokia | 5140i |
| Mobile Phone / PDA | Nokia | 3589i |

| | | |
|--------------------|-------|--------------|
| Mobile Phone / PDA | Nokia | 3588i |
| Mobile Phone / PDA | Nokia | 3587i |
| Mobile Phone / PDA | Nokia | 3586i |
| Mobile Phone / PDA | Nokia | 3585i |
| Mobile Phone / PDA | Nokia | 3510i |
| Mobile Phone / PDA | Nokia | 2600 classic |
| Mobile Phone / PDA | Nokia | 252NC |
| Mobile Phone / PDA | Nokia | 252N |
| Mobile Phone / PDA | Nokia | 252CC |
| Mobile Phone / PDA | Nokia | 2128i |
| Mobile Phone / PDA | Nokia | 2126i |
| Mobile Phone / PDA | Nokia | 5165i |
| Mobile Phone / PDA | Nokia | 8390 |
| Mobile Phone / PDA | Nokia | 7260 |
| Mobile Phone / PDA | Nokia | 7250 |
| Mobile Phone / PDA | Nokia | 7210 |
| Mobile Phone / PDA | Nokia | 7200 |
| Mobile Phone / PDA | Nokia | 7190 |
| Mobile Phone / PDA | Nokia | 7160 |
| Mobile Phone / PDA | Nokia | 7110 |
| Mobile Phone / PDA | Nokia | 7100 |
| Mobile Phone / PDA | Nokia | 6822 |
| Mobile Phone / PDA | Nokia | 6820 |
| Mobile Phone / PDA | Nokia | 6810 |
| Mobile Phone / PDA | Nokia | 6800 |
| Mobile Phone / PDA | Nokia | 6682 |
| Mobile Phone / PDA | Nokia | 6681 |
| Mobile Phone / PDA | Nokia | 7270 |
| Mobile Phone / PDA | Nokia | 7280 |
| Mobile Phone / PDA | Nokia | 8310 |
| Mobile Phone / PDA | Nokia | 8290 |
| Mobile Phone / PDA | Nokia | 8280 |
| Mobile Phone / PDA | Nokia | 8270 |
| Mobile Phone / PDA | Nokia | 8265 |
| Mobile Phone / PDA | Nokia | 8260 |
| Mobile Phone / PDA | Nokia | 8250 |
| Mobile Phone / PDA | Nokia | 8210 |

| | | |
|--------------------|-------|-----------------|
| Mobile Phone / PDA | Nokia | 7710 |
| Mobile Phone / PDA | Nokia | 7700 |
| Mobile Phone / PDA | Nokia | 7650 |
| Mobile Phone / PDA | Nokia | 7610 |
| Mobile Phone / PDA | Nokia | 7600 |
| Mobile Phone / PDA | Nokia | 7380 |
| Mobile Phone / PDA | Nokia | 6680 |
| Mobile Phone / PDA | Nokia | 5170i |
| Mobile Phone / PDA | Nokia | THR880 |
| Mobile Phone / PDA | Nokia | BMH-8 |
| Mobile Phone / PDA | Nokia | BMH-7 |
| Mobile Phone / PDA | Nokia | BMH-3 |
| Mobile Phone / PDA | Nokia | BMH-2 |
| Mobile Phone / PDA | Nokia | BMC-3 |
| Mobile Phone / PDA | Nokia | BMC-2 |
| Mobile Phone / PDA | Nokia | BLN-3 |
| Mobile Phone / PDA | Nokia | BLC-2 |
| Mobile Phone / PDA | Nokia | BL-6C |
| Mobile Phone / PDA | Nokia | BL-5X |
| Mobile Phone / PDA | Nokia | BL-5C |
| Mobile Phone / PDA | Nokia | BL-5B |
| Mobile Phone / PDA | Nokia | BL-4C |
| Mobile Phone / PDA | Nokia | BKL-6 |
| Mobile Phone / PDA | Nokia | BMP-1A |
| Mobile Phone / PDA | Nokia | BP-5L |
| Mobile Phone / PDA | Nokia | THR850 |
| Mobile Phone / PDA | Nokia | SHORTY |
| Mobile Phone / PDA | Nokia | PCS 5120 |
| Mobile Phone / PDA | Nokia | N-VAGE QD |
| Mobile Phone / PDA | Nokia | Nokia N-Cage QD |
| Mobile Phone / PDA | Nokia | Nokia N-Cage |
| Mobile Phone / PDA | Nokia | N-GageQD |
| Mobile Phone / PDA | Nokia | N-GAGE QD |
| Mobile Phone / PDA | Nokia | N-Gage |
| Mobile Phone / PDA | Nokia | N-CAGE |
| Mobile Phone / PDA | Nokia | NBK252 |
| Mobile Phone / PDA | Nokia | MML-7 |

| | | |
|--------------------|-------|----------------|
| Mobile Phone / PDA | Nokia | E70 |
| Mobile Phone / PDA | Nokia | E60 |
| Mobile Phone / PDA | Nokia | BKH-6 |
| Mobile Phone / PDA | Nokia | 9300i |
| Mobile Phone / PDA | Nokia | 6185i |
| Mobile Phone / PDA | Nokia | 6162i |
| Mobile Phone / PDA | Nokia | 6162 Flip |
| Mobile Phone / PDA | Nokia | 6161i |
| Mobile Phone / PDA | Nokia | 6161 Flip |
| Mobile Phone / PDA | Nokia | 6160i |
| Mobile Phone / PDA | Nokia | 6120i |
| Mobile Phone / PDA | Nokia | 6101 (classic) |
| Mobile Phone / PDA | Nokia | 6019i |
| Mobile Phone / PDA | Nokia | 6016i |
| Mobile Phone / PDA | Nokia | 6015i |
| Mobile Phone / PDA | Nokia | 6011i |
| Mobile Phone / PDA | Nokia | 5300 (Classic) |
| Mobile Phone / PDA | Nokia | 5185i |
| Mobile Phone / PDA | Nokia | 6230i |
| Mobile Phone / PDA | Nokia | 6235i |
| Mobile Phone / PDA | Nokia | 9210i |
| Mobile Phone / PDA | Nokia | 9110i |
| Mobile Phone / PDA | Nokia | 8910i |
| Mobile Phone / PDA | Nokia | 8850 Gold |
| Mobile Phone / PDA | Nokia | 8265i |
| Mobile Phone / PDA | Nokia | 7250i |
| Mobile Phone / PDA | Nokia | 6820i |
| Mobile Phone / PDA | Nokia | 6610i |
| Mobile Phone / PDA | Nokia | 6590i |
| Mobile Phone / PDA | Nokia | 6340i |
| Mobile Phone / PDA | Nokia | 6310i |
| Mobile Phone / PDA | Nokia | 6256i |
| Mobile Phone / PDA | Nokia | 6255i |
| Mobile Phone / PDA | Nokia | 6236i |
| Mobile Phone / PDA | Nokia | 5180i |
| Mobile Phone / PDA | Nokia | 6670 |
| Mobile Phone / PDA | Nokia | 3595 |

| | | |
|--------------------|-------|------|
| Mobile Phone / PDA | Nokia | 3315 |
| Mobile Phone / PDA | Nokia | 3310 |
| Mobile Phone / PDA | Nokia | 3285 |
| Mobile Phone / PDA | Nokia | 3230 |
| Mobile Phone / PDA | Nokia | 3220 |
| Mobile Phone / PDA | Nokia | 3210 |
| Mobile Phone / PDA | Nokia | 3205 |
| Mobile Phone / PDA | Nokia | 3200 |
| Mobile Phone / PDA | Nokia | 3125 |
| Mobile Phone / PDA | Nokia | 3120 |
| Mobile Phone / PDA | Nokia | 3108 |
| Mobile Phone / PDA | Nokia | 3105 |
| Mobile Phone / PDA | Nokia | 3100 |
| Mobile Phone / PDA | Nokia | 2652 |
| Mobile Phone / PDA | Nokia | 3330 |
| Mobile Phone / PDA | Nokia | 3350 |
| Mobile Phone / PDA | Nokia | 3590 |
| Mobile Phone / PDA | Nokia | 3586 |
| Mobile Phone / PDA | Nokia | 3585 |
| Mobile Phone / PDA | Nokia | 3570 |
| Mobile Phone / PDA | Nokia | 3560 |
| Mobile Phone / PDA | Nokia | 3530 |
| Mobile Phone / PDA | Nokia | 3520 |
| Mobile Phone / PDA | Nokia | 3510 |
| Mobile Phone / PDA | Nokia | 3410 |
| Mobile Phone / PDA | Nokia | 3395 |
| Mobile Phone / PDA | Nokia | 3390 |
| Mobile Phone / PDA | Nokia | 3385 |
| Mobile Phone / PDA | Nokia | 3361 |
| Mobile Phone / PDA | Nokia | 3360 |
| Mobile Phone / PDA | Nokia | 2651 |
| Mobile Phone / PDA | Nokia | 2650 |
| Mobile Phone / PDA | Nokia | 2112 |
| Mobile Phone / PDA | Nokia | 2100 |
| Mobile Phone / PDA | Nokia | 1600 |
| Mobile Phone / PDA | Nokia | 1261 |
| Mobile Phone / PDA | Nokia | 1260 |

| | | |
|--------------------|-------|------|
| Mobile Phone / PDA | Nokia | 1221 |
| Mobile Phone / PDA | Nokia | 1112 |
| Mobile Phone / PDA | Nokia | 1110 |
| Mobile Phone / PDA | Nokia | 1108 |
| Mobile Phone / PDA | Nokia | 1101 |
| Mobile Phone / PDA | Nokia | 1100 |
| Mobile Phone / PDA | Nokia | 650 |
| Mobile Phone / PDA | Nokia | 640 |
| Mobile Phone / PDA | Nokia | 282 |
| Mobile Phone / PDA | Nokia | 2116 |
| Mobile Phone / PDA | Nokia | 2118 |
| Mobile Phone / PDA | Nokia | 2626 |
| Mobile Phone / PDA | Nokia | 2610 |
| Mobile Phone / PDA | Nokia | 2600 |
| Mobile Phone / PDA | Nokia | 2310 |
| Mobile Phone / PDA | Nokia | 2300 |
| Mobile Phone / PDA | Nokia | 2285 |
| Mobile Phone / PDA | Nokia | 2280 |
| Mobile Phone / PDA | Nokia | 2275 |
| Mobile Phone / PDA | Nokia | 2270 |
| Mobile Phone / PDA | Nokia | 2260 |
| Mobile Phone / PDA | Nokia | 2255 |
| Mobile Phone / PDA | Nokia | 2128 |
| Mobile Phone / PDA | Nokia | 2126 |
| Mobile Phone / PDA | Nokia | 2125 |
| Mobile Phone / PDA | Nokia | 252 |
| Mobile Phone / PDA | Nokia | 3600 |
| Mobile Phone / PDA | Nokia | 6651 |
| Mobile Phone / PDA | Nokia | 6250 |
| Mobile Phone / PDA | Nokia | 6235 |
| Mobile Phone / PDA | Nokia | 6230 |
| Mobile Phone / PDA | Nokia | 6225 |
| Mobile Phone / PDA | Nokia | 6220 |
| Mobile Phone / PDA | Nokia | 6210 |
| Mobile Phone / PDA | Nokia | 6200 |
| Mobile Phone / PDA | Nokia | 6190 |
| Mobile Phone / PDA | Nokia | 6185 |

| | | |
|--------------------|-------|------|
| Mobile Phone / PDA | Nokia | 6180 |
| Mobile Phone / PDA | Nokia | 6170 |
| Mobile Phone / PDA | Nokia | 6168 |
| Mobile Phone / PDA | Nokia | 6162 |
| Mobile Phone / PDA | Nokia | 6161 |
| Mobile Phone / PDA | Nokia | 6255 |
| Mobile Phone / PDA | Nokia | 6260 |
| Mobile Phone / PDA | Nokia | 6650 |
| Mobile Phone / PDA | Nokia | 6630 |
| Mobile Phone / PDA | Nokia | 6620 |
| Mobile Phone / PDA | Nokia | 6610 |
| Mobile Phone / PDA | Nokia | 6600 |
| Mobile Phone / PDA | Nokia | 6590 |
| Mobile Phone / PDA | Nokia | 6585 |
| Mobile Phone / PDA | Nokia | 6560 |
| Mobile Phone / PDA | Nokia | 6510 |
| Mobile Phone / PDA | Nokia | 6385 |
| Mobile Phone / PDA | Nokia | 6370 |
| Mobile Phone / PDA | Nokia | 6360 |
| Mobile Phone / PDA | Nokia | 6340 |
| Mobile Phone / PDA | Nokia | 6310 |
| Mobile Phone / PDA | Nokia | 6160 |
| Mobile Phone / PDA | Nokia | 6150 |
| Mobile Phone / PDA | Nokia | 5180 |
| Mobile Phone / PDA | Nokia | 5170 |
| Mobile Phone / PDA | Nokia | 5165 |
| Mobile Phone / PDA | Nokia | 5160 |
| Mobile Phone / PDA | Nokia | 5140 |
| Mobile Phone / PDA | Nokia | 5130 |
| Mobile Phone / PDA | Nokia | 5125 |
| Mobile Phone / PDA | Nokia | 5120 |
| Mobile Phone / PDA | Nokia | 5110 |
| Mobile Phone / PDA | Nokia | 5100 |
| Mobile Phone / PDA | Nokia | 3660 |
| Mobile Phone / PDA | Nokia | 3650 |
| Mobile Phone / PDA | Nokia | 3620 |
| Mobile Phone / PDA | Nokia | 3610 |

| | | |
|--------------------|-------|------|
| Mobile Phone / PDA | Nokia | 5185 |
| Mobile Phone / PDA | Nokia | 5190 |
| Mobile Phone / PDA | Nokia | 5210 |
| Mobile Phone / PDA | Nokia | 6130 |
| Mobile Phone / PDA | Nokia | 6120 |
| Mobile Phone / PDA | Nokia | 6110 |
| Mobile Phone / PDA | Nokia | 6108 |
| Mobile Phone / PDA | Nokia | 6100 |
| Mobile Phone / PDA | Nokia | 6062 |
| Mobile Phone / PDA | Nokia | 6061 |
| Mobile Phone / PDA | Nokia | 6060 |
| Mobile Phone / PDA | Nokia | 6030 |
| Mobile Phone / PDA | Nokia | 6021 |
| Mobile Phone / PDA | Nokia | 6020 |
| Mobile Phone / PDA | Nokia | 6015 |
| Mobile Phone / PDA | Nokia | 6010 |
| Mobile Phone / PDA | Nokia | 5510 |
| MP3 / MP4 | VuGo | VuGo |